



Connect camera to J3 using one of the following:

JST - connector type SHR-07V-S

60C1044 - 2xD389/439/479 camera I²C cable


60C1045 - 2xK13x/14x/15x camera I²C cable

60C1046 - 2xK13xCB /14xCB /15xCB camera I²C cable

60C1047 - 2xK13xYC/14xYC/15xYC camera I²C cable

60C1084 - 2xD35x0 camera I²C cable

60C1085 - 2xD35xB camera I²C cable



Connect computer's parallel port to J1 using the following:
60C0102 - 25pin male-to-male straight through cable

Connector J2 - no connection needed

Connector J4 - no connection needed